


PROGRAMMING SHADE MOTORS

TURNING "SOFT STOP" ON AND OFF



BACK OF REMOTE
WITH COVER REMOVED



FRONT OF REMOTE

"Soft Stop" is a feature available on remote control motors that can be turned off or on. When "Soft Stop" is turned on, the shade movement will slow as the shade approaches its upper, lower, or middle stop limits. Shades ship with this feature automatically turned off.

HOW TO TURN IT ON:

1. Remove back cover.
2. Press **P2** (shade will jog and beep), **UP** (shade will jog and beep), then **UP** again (shade will jog only).
3. Repeat step 2 until a long beep sounds after the second **UP**, indicating "Soft Stop" has been turned on.

HOW TO TURN IT OFF:

1. Remove back cover
2. Press **P2** (shade will jog and beep), **DOWN** (shade will jog and beep), then **DOWN** again (shade will jog only).
3. Repeat step 2 until the shade no longer jogs on the second **DOWN**, indicating "Soft Stop" has been turned off.